

## **Rotisserie Chart**

## Proper lighting technique

Check for spark

Check connection (ignition wire) from valve and back electrode

Ţ

If no spark clean around electrode point

If spark is not present after cleaning electrode and ignition wire

Contact a Bull Authorized Service Center or a qualified technician If sparking and burner is not igniting try to slightly bend the electrode points closer to the burner

Test ignition system by using proper lighting technique, see "Rotisserie Cooking" in manual

If the problem persists, contact a Bull Authorized Service Center or a qualified technician Cautiously ignite backburner with long fireplace style lighter to ensure burner has proper gas flow burner should glow bright red

If all steps have been conducted and are unsuccessful please contact tech service at Bull